









STANDARD SCREW SPACING FOR TECTUM PLANK SYSTEMS


THE LOCATION OF ATTACHMENT SCREWS FOR TECTUM ROOF DECK PRODUCTS IS OFTEN VARIED. THIS DRAWING GIVES TECTUM INC. RECOMMENDED LOCATIONS. IT SHOULD BE NOTED THAT THE SCREWS ARE NOT PLACED AT THE EDGE OF THE PANELS BUT ARE SPACED IN FROM THE EDGE DEPENDING ON THE WIDTH OF THE PANELS AND THE NUMBER OF SCREWS PER JOIST. SPECIAL APPLICATIONS MAY REQUIRE SOME MODIFICATION OF THE SPACING SHOWN.



1 SCREW SPACING

Scale: N.T.S.

These drawings show typical conditions in which the Armstrong product depicted is installed. They are not a substitute for an architect's or engineer's plan and do not reflect the unique requirements of local building codes, laws, statutes, ordinances, rules and regulations (Legal Requirements) that may be applicable for a particular installation. Armstrong does not warrant, and assumes no liability for the accuracy or completeness of the drawings for a particular installation or their fitness for a particular purpose. The user is advised to consult with a duly licensed architect or engineer in the particular locale of the installation to assure compliance with all Legal Requirements. Armstrong is not licensed to provide professional architecture or engineering design services.

PROJECT NAME: SCREW SPACING			 CEILING & WALL SOLUTIONS		
DATE: 10-16-17	SCALE: N.T.S.	PROJECT NO.: XXX			DRAWN BY: KBD
REV:	DATE:	DESC.: 2022-SCREW SPACING			SHEET SK1 1 OF 1
REV:	DATE:				